WEBER-HYDRAULIK

General installation instructions
for seal sets

110220_installation_seal_sets
02/2022

Operating and safety instructions

Information regarding installation, set up and maintenance is available on our website under *"General operating instructions"* or on request. Before work can be started on one of our products, the general operating instructions of WEBER-HYDRAULIK GMBH in Konstanz must be read.
Installation, set up and operation, removal, servicing (including maintenance and care) require fundamental mechanical/electrical/hydraulic knowledge, as well as knowledge of the corresponding technical terms. In order to guarantee occupational safety, these tasks may therefore only be performed by an appropriate specialist or a trained person under the supervision of a specialist.
A specialist is a person who, due to their technical training, knowledge and experience, as well as their knowledge of the applicable regulations is able to evaluate the work assigned to them, identify potential hazards and take suitable safety measures. A specialist must comply with the applicable technical regulations. Also observe the generally applicable, legal and other binding regulations of European or national legislation, as well as the accident prevention and environmental protection regulations that are applicable in your country.
The specified data is provided solely to describe the product. A statement on a particular feature or suitability for a specific application cannot be derived from our specifications. The specifications do not release the user from their own evaluations and checks. Note that our products are subject to a natural wear and aging process.

Installation

Proceed with caution when installing the seal set. Do not use any sharp tools that could damage the seal and do not guide the seal over rough or sharp surfaces. Minimize the seal stretching during installation. Use suitable O-ring installation tools. Screwdrivers and awls are not suitable installation tools.

Note that the sealing material must be compatible with the hydraulic fluid used in the system and the lubricants for installation. Most valve have internal seals that can only be replaced by dismantling the valve properly. Simply replacing the external seals is not sufficient to convert the valve to new sealing material. Please contact our customer service department.

NOTE Before installing the seal set, read the corresponding product data sheet that is available on our website under *"Valve catalog"* or on request.

Technical data

The warranty applies only to the delivered configuration. The warranty is invalidated in the event of improper installation, improper use and/or improper handling.

WEBER-HYDRAULIK GMBH
Felix-Wankel-Str. 4, 78467 Konstanz, Germany
Phone: +49 7531 9748-0
Fax: +49 7531 9748-44
www.weber-hydraulik.com
info.de-k@weber-hydraulik.com

Subject to changes